

PBR-Panel

Metal Roof and Wall Panel

Installation Manual

IMPORTANT INFORMATION

The application and detail drawings in this manual are strictly for illustration purposes and may not be applicable to all building designs or product installations. All projects should conform to applicable building codes for that particular area. It is recommended to follow all building regulations and standard industry practices.

Metal Sales Manufacturing Corporation is not responsible for the performance of the roof system if it is not installed in accordance with the suggested instructions referenced in this manual. If there is a conflict between this manual and the approved Metal Sales' erection drawings, the approved erection drawings are to take precedence.

Prior to ordering and installing materials, all dimensions should be verified by field measurements.

Oil canning is not a cause for rejection. Oil canning can be described as the amount of waviness found in the flat areas of metal panels. Oil canning is an inherent characteristic of light gauge cold formed metal products, particularly those with broad flat areas. There are many factors which may contribute to oil canning that Metal Sales is not able to control. These factors include: misalignment of the support system, over driving of fasteners used on the panels, stress (whether inherent in the panel or induced), thermal expansion and contraction of the panel, material handling, width, gauge, length, color of panels, and installation. (Reference Metal Construction Association "Oil Canning Position Paper" - Appendix A).

Metal Sales reserves the right to modify, without notice, any details, recommendations or suggestions. Any questions you may have regarding proper installation of the Magna-Loc roofing system should be directed to your Metal Sales representative, (see pages 2 and 3).

Consult Metal Sales for any additional information not outlined in this manual.

This manual is designed to be utilized as a guide when installing Magna-Loc roofing system. It is the responsibility of the erector to ensure the safe installation of this product system.

SAFETY

STUDY APPLICABLE OSHA AND OTHER SAFETY REQUIREMENTS BEFORE FOLLOWING THESE INSTRUCTIONS.

The installation of metal roof systems is a dangerous procedure and should be supervised by trained knowledgeable erectors. USE EXTREME CARE WHILE INSTALLING ROOF PANELS. It is not possible for Metal Sales to be aware of all the possible job site situations that could cause an unsafe condition to exist. The erector of the roof system is responsible for reading these instructions and determining the safest way to install the roof system.

These instructions are provided only as a guide to show a knowledgeable, trained erector the correct parts placement one to another. If following any of the installation steps would endanger a worker, the erector should stop work and decide upon a corrective action.


Provide required safety railing, netting, or safety lines for crew members working on the roof.

Do not use the roof panel as a walking platform. The roof panels will not withstand the weight of a person standing at the edge of the panel.

Do not stand on any part of a roof panel until the panel has been completely attached.



773 metal sales manufacturing corporation



NOTE: Shaded areas represent regions served by each location.

Branches that manufacture PBR-Panel and/or R-Panel

Metal Sales offers a complete line of metal roof, wall, and fascia panel systems for the commercial, architectural, industrial, residential, and agricultural markets. Metal Sales offers over 75 profiles with a wide selection of widths, colors, and gauges - new construction or retrofit.



BRANCH CONTACT INFORMATION

1.) DENVER BRANCH

7990 E. I-25 Frontage Road Longmont, CO 80504 303.702.5440 Phone 800.289.7663 Toll Free 800.289.1617 Toll Free Fax

2.) JACKSONVILLE BRANCH

7110 Stuart Avenue Jacksonville, FL 32254 904.783.3660 Phone 800.394.4419 Toll Free 904.783.9175 Fax 800.413.3292 Toll Free Fax

3.) JEFFERSON BRANCH

352 East Erie Street Jefferson, OH 44047 440.576.9070 Phone 800.321.5833 Toll Free 440.576.9242 Fax 800.233.5719 Toll Free Fax

4.) INDEPENDENCE BRANCH

1306 S. Powell Road Independence, MO 64057 816.796.0900 Phone 800.747.0012 Toll Free 816.796.0906 Fax

5.) SELLERSBURG BRANCH

7800 State Road 60 Sellersburg, IN 47172 812.246.1866 Phone 800.999.7777 Toll Free 812.246.0893 Fax 800.477.9318 Toll Free Fax

6.) ROGERS BRANCH

22651 Industrial Blvd. Rogers, MN 55374 763.428.8080 Phone 800.328.9316 Toll Free 763.428.8525 Fax 800.938.9119 Toll Free Fax

7.) NASHVILLE BRANCH

4314 Hurricane Creek Blvd. Antioch, TN 37013 615.641.7100 Phone 800.251.8508 Toll Free 615.641.7118 Fax 800.419.4372 Toll Free Fax

8.) SPOKANE BRANCH

East 2727 Trent Avenue Spokane, WA 99202 509.536.6000 Phone 800.572.6565 Toll Free 509.534.4427 Fax

9.) SEATTLE BRANCH

20213 84th Avenue, South Kent, WA 98032 253.872.5750 Phone 800.431.3470 Toll Free (Outside WA) 800.742.7900 Toll Free (Inside WA) 253.872.2008 Fax

11.) ROCK ISLAND BRANCH

8111 West 29th Street Rock Island, IL 61201 309.787.1200 Phone 800.747.1206 Toll Free 309.787.1833 Fax

12.) DEER LAKE BRANCH

29 Pinedale Industrial Road Orwigsburg, PA 17961 570.366.2020 Phone 800.544.2577 Toll Free 570.366.1648 Fax 800.544.2574 Toll Free Fax

13.) TEMPLE BRANCH

3838 North General Bruce Dr. Temple, TX 76501 254.791.6650 Phone 800.543.4415 Toll Free 254.791.6655 Fax 800.543.4473 Toll Free Fax

14.) WOODLAND BRANCH

1326 Paddock Place Woodland, CA 95776 530.668.5690 Phone 800.759.6019 Toll Free 530.668.0901 Fax

15.) FONTANA BRANCH

14213 Whittram Avenue Fontana, CA 92335 909.829.8618 Phone 800.782.7953 Toll Free 909.829.9083 Fax

16.) ANCHORAGE BRANCH

4637 Old Seward Hwy. Anchorage, AK 99503 907.646.7663 Phone 866.640.7663 Toll Free 907.646.7664 Fax

17.) BAY CITY BRANCH

5209 Mackinaw Road Bay City, MI 48706 989.686.5879 Phone 888.777.7640 Toll Free 989.686.5870 Fax 888.777.0112 Toll Free Fax

18.) DETROIT LAKES BRANCH

1435 Egret Avenue Detroit Lakes, MN 56501 218.847.2988 Phone 888.594.1394 Toll Free 218.847.4835 Fax 888.594.1454 Toll Free Fax

19.) MOCKSVILLE BRANCH

188 Quality Drive Mocksville, NC 27028 336.751.6381 Phone 800.228.6119 Toll Free 336.751.6301 Fax 800.228.7916 Toll Free Fax

20.) FORT SMITH BRANCH

7510 Ball Road Fort Smith, AR 72908 479.646.1176 Phone 877.452.3915 Toll Free 479.646.5204 Fax

21.) SIOUX FALLS BRANCH

2700 West 3rd Street, Suite 4 Sioux Falls, SD 57104 605.335.2745 Phone 888.297.0024 Toll Free

TECHNICAL SUPPORT


TECHNICAL SERVICES

545 South 3rd Street Louisville, KY 40202 502.855.4300 Phone 800.406.7387 Toll Free 502.855.4290 Fax 800.944.6884 Toll Free Fax




PANEL OVERVIEW

PBR-PANEL PROFILE



R-PANEL PROFILE



SLOPE

The minimum recommended slope for any "R" and "PBR"-Panel is 1:12. Metal Sales recommends that in all roof applications sealant be used on sidelaps.

SUBSTRATE

R-Panel is designed to be utilized over open structural framing, but can easily be used with a solid substrate. The recommended substrate is $^5/8$ " plywood with a 30 pound felt moisture barrier. To avoid panel distortion, use a properly aligned and uniform substructure. **PBR-Panel is recommended for roof applications.**

COVERAGE

Each panel has a coverage of 36".

LENGTH

Lengths under 5'-0" are available with some cutting restrictions. Maximum recommended panel length is 45'-0". Longer panels require additional consideration in packaging, shipping, and erection. Please consult your Metal Sales branch for recommendations.

AVAILABILITY

Panels are available in 26, 24, and 22 gauge. Minimums quantities may apply.

APPLICATION

Commercial, Industrial, and Architectural panels.

PERFORMANCE TEST

UL 580, UL 2218, UL 790, Texas Department of Insurance, Cantilever Diaphragm.

FASTENING SYSTEM

Direct Fastened (exposed).

FASTENERS

The fastener selection guide should be consulted for choosing proper fasteners for specific applications. Quantity and type of fastener must meet necessary loading and code requirements (see PGI-12-14).

MATERIALS


Steel grade 50 per ASTM A-792 Steel grade 80 per ASTM A-792 or ASTM A-653

FINISH

- *Acrylic Coated Galvalume® (ACG) / ASTM A-792 AZ55
- ► Pre-painted Galvalume / ASTM A-792 AZ50
- ► MS Colorfast45®
- "PVDF (Kynar 500)
 - Differential appearance of Acrylic Coated Galvalume roofing materials is not a cause for rejection.
 - ** Meets both Kynar 500 and Hylar 5000 specifications.



PBR-PANEL PROFILE




FINISH	GAUGE	COVERAGE	PRODUCT NO.	WT/SQ
ACG	26	36"	2505241	83
MS Colorfast45®	26	36"	25052	83
PVDF Standard•	26	36"	26052	83
ACG	24	36"	2505241	106
PVDF Standard*	24	36"	26052	106

• See Metal Sales color charts for color selection. _ _ Represents color code

*Additional lead time required.

R-PANEL PROFILE



FINISH	GAUGE	COVERAGE	PRODUCT NO.	WT/SQ
ACG	26	36"	2505241	83
MS Colorfast45®	26	36"	25052	83
PVDF Standard◆	26	36"	26052	83
ACG	24	36"	2505241	106
PVDF Standard◆	24	36"	26052	106

• See Metal Sales color charts for color selection. _ _ Represents color code

*Additional lead time required.

PANEL NOTES

- 1. For panel lengths over 45'-0", please inquire.
- 2. Panels may be installed over structural framing or solid substrate.
- 3. Minimum recommended roof slope: 1:12. Sidelap sealant and stitch screws required on less than 3:12 slope.
- 4. Finishes:
 - MS Colorfast45®
 - PVDF (Kynar 500)



PBR-PANEL FLASHING PROFILES **GAUGE FINISH** PRODUCT NO. **WEIGHT** LENGTH 20" RIDGE/HIP COVER 26 **ACG** 5500641 13.90 lbs 10'-2" 26 **ACG** 5500841 27.80 lbs 20'-3" 55006__ 26 MS Colorfast45® 13.90 lbs 10'-2" 55008__ 26 MS Colorfast45® 27.80 lbs 20'-3" 10 56006__ **PVDF** 26 13.90 lbs 10'-2" 26 **PVDF** 27.80 lbs 20'-3" 56008_ _ Hem 24 **ACG** 5700641 10'-2" 15.90 lbs 24 5700841 20'-3" ACG 31.80 lbs 10'-2" 24 **PVDF** 15.90 lbs 58006 * See chart on page GI-8 24 20'-3" **PVDF** 58008 31.80 lbs **GAUGE** PRODUCT NO. **WEIGHT UNIVERSAL RIDGE COVER** FINISH LENGTH 26 5501041 13.90 lbs 10'-2" **ACG** 26 MS Colorfast45® 55010__ 13.90 lbs 10'-2" 26 **PVDF** 56010 13.90 lbs 10'-2" 24 **ACG** 5701041 15.90 lbs 10'-2" 24 **PVDF** 58010 15.90 lbs 10'-2" * See chart on page XX **GAUGE FINISH** PRODUCT NO. **WEIGHT** LENGTH **PBR-PANEL FORMED RIDGE** 26 **ACG** 5592141 9.00 lbs 18" 26 MS Colorfast45® 55921__ 9.00 lbs 18" 26 **PVDF** 56921 9.00 lbs 18" 24 5672141 10.10 lbs 18" ACG **PVDF** 24 10.10 lbs 18" 56722__ 36" * See chart on page GI-8, Angle same as Ridge/Hip Cover. **4:12 Maximum slope on all Formed Ridge (Please inquire on minimum quantities required) **FINISH** PRODUCT NO. **WEIGHT** LENGTH **GAUGE VALLEY** 26 **ACG** 5301841 13.90 lbs 10'-2" **ACG** 5502041 27.80 lbs 20'-3" 26 53018__ 26 MS Colorfast45® 13.90 lbs 10'-2" 26 MS Colorfast45® 55020__ 27.80 lbs 20'-3" 54018__ 26 **PVDF** 10'-2" 13.90 lbs 26 **PVDF** 56020__ 27.80 lbs 20'-3" 10" 10'-2" 24 **ACG** 5701841 16.85 lbs 20'-3" 24 ACG 5702041 33.70 lbs 58018__ 24 **PVDF** 16.85 lbs 10'-2" 58020__ 24 **PVDF** 33.70 lbs 20'-3" **GAUGE FINISH** PRODUCT NO. LENGTH WEIGHT **EAVE** 10'-2" 26 **ACG** 5506941 6.00 lbs 4⁷/8" 26 MS Colorfast45® 55069__ 6.00 lbs 10'-2" 26 **PVDF** 56069__ 10'-2" 6.00 lbs 24 **ACG** 5706941 7.00 lbs 10'-2" 58069__ 24 **PVDF** 7.00 lbs 10'-2" 5/8" Hem സ്ട്ര metal sales

© Metal Sales Manufacturing Corporation / Subject to change without notice 12/11

6

PBR-PANEL FLASHING PROFILES

PBR-PANEL	FLASH	IING PROFIL	.ES		
BOX GUTTER	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
3 ¹ / ₂ " 1" Hem 1" 1"	26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF	5507741 5507941 55077 55079 56077 56079	14.00 lbs 28.00 lbs 14.00 lbs 28.00 lbs 14.00 lbs 28.00 lbs	10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3"
5" 4" C	24 24 24 24	ACG ACG PVDF PVDF	5707741 5707941 58077 58079	16.95 lbs 33.90 lbs 16.95 lbs 33.90 lbs	10'-2" 20'-3" 10'-2" 20'-3"
BOX GUTTER END CAP	GAUGE	FINISH	PRODUCT NO.	WEIGHT	SIDE
5" 4" 1"	26 26 26 26 26 26 26 24 24 24 24	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF ACG ACG PVDF PVDF	5508141 5508241 55081 55082 56081 56082 5708141 5708241 58081 58082	.20 lbs .20 lbs .20 lbs .20 lbs .20 lbs .20 lbs .24 lbs .24 lbs .24 lbs	Left Right Left Right Left Right Left Right Left Right
SCULPTURED GUTTER	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
11/2" C 11/2" 31/2" X*	26 26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF	5508441 5508641 55084 55086 56084 56086	14.00 lbs 28.00 lbs 14.00 lbs 28.00 lbs 14.00 lbs 28.00 lbs	10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3"
Varies with slope* 150° 31/2" 105°	24 24 24 24	ACG ACG PVDF PVDF	5708441 5708641 58084 58086	16.95 lbs 33.90 lbs 16.95 lbs 33.90 lbs	10'-2" 20'-3" 10'-2" 20'-3"
SCULPTURED GUTTER END CAP	GAUGE	FINISH	PRODUCT NO.	WEIGHT	SIDE
5 ¹ / ₂ "	26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF	5508841 5508941 55088 55089 56088 56089	.20 lbs .20 lbs .20 lbs .20 lbs .20 lbs .20 lbs	Left Right Left Right Left Right
105° \[3^{1/2}'' \] \[6'' \]	24 24 24 24 24	ACG ACG PVDF PVDF	5708841 5708941 58088 58089	.24 lbs .24 lbs .24 lbs .24 lbs	Left Right Left Right
4					


FLASHING PROFILES

BOX GUTTER/DOWNSPOUT STRAP
Hem


GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
26	ACG	5509241	.32 lbs	1'-4"
26	MS Colorfast45®	55092	.32 lbs	1'-4"
26	PVDF	56092	.32 lbs	1'-4"
24	ACG	5709241	.36 lbs	1'-4"
24	PVDF	58092	.36 lbs	1'-4"

	GUTTER HANGAR
	1" C 11/2" C 135° C
п	

GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
26	ACG	5509141	.32 lbs	1'-0"
26	MS Colorfast45®	55091	.32 lbs	1'-0"
26	PVDF	56091	.32 lbs	1'-0"
24	ACG	5709141	.41 lbs	1'-0"
24	PVDF	58091	.41 lbs	1'-0"



GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
26	ACG	5509441	13.90 lbs	10'-2"
26	ACG	5509741	27.80 lbs	20'-3"
26	MS Colorfast45®	55094	13.90 lbs	10'-2"
26	MS Colorfast45®	55097	27.80 lbs	20'-3"
26	PVDF	56094	13.90 lbs	10'-2"
26	PVDF	56097	27.80 lbs	20'-3"
24	ACG	5709441	16.85 lbs	10'-2"
24	ACG	5709741	33.70 lbs	20'-3"
24	PVDF	58094	16.85 lbs	10'-2"
24	PVDF	58097	33.70 lbs	20'-3"



6" X 4" DOWNSPOUT

GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
26	ACG	5509841	13.90 lbs	10'-2"
26	ACG	5510141	27.80 lbs	20'-3"
26	MS Colorfast45®	55098	13.90 lbs	10'-2"
26	MS Colorfast45®	55101	27.80 lbs	20'-3"
26	PVDF	56098	13.90 lbs	10'-2"
26	PVDF	56101	27.80 lbs	20'-3"
				_, _,
24	ACG	5709841	16.85 lbs	10'-2"
24	ACG	5710141	33.70 lbs	20'-3"
24	PVDF	58098	16.85 lbs	10'-2"
24	PVDF	58101	33.70 lbs	20'-3"
24	I VDI	30101	33.70 103	20-3

PBR-PANEL FLASHING PROFILES **GAUGE** FINISH PRODUCT NO. **WEIGHT 4" DOWNSPOUT STRAP** 26 **ACG** 5511041 .32 lbs 55110__ 26 MS Colorfast45® .32 lbs 26 **PVDF** 56110 .32 lbs 5711041 24 ACG .36 lbs 24 **PVDF** 58110__ .36 lbs **GAUGE FINISH** PRODUCT NO. **WEIGHT 6" DOWNSPOUT STRAP** 26 ACG 5511241 .32 lbs 26 MS Colorfast45® 55112__ .32 lbs 56112__ 26 **PVDF** .32 lbs 24 5711241 **ACG** .36 lbs 24 **PVDF** 58112__ .36 lbs **GAUGE FINISH** PRODUCT NO. **WEIGHT TYPE** 4" X 3-1/2" ELBOW 5510241 26 **ACG** 2.00 lbs 95 Degree 55102__ 26 MS Colorfast45® 2.00 lbs 95 Degree 56102 26 **PVDF** 2.00 lbs 95 Degree 24 **ACG** 5710241 2.30 lbs 95 Degree 24 **PVDF** 2.30 lbs 95 Degree 58102 26 **ACG** 5510641 2.00 lbs 45 Degree 55106__ 26 MS Colorfast45® 2.00 lbs 45 Degree 26 **PVDF** 56106 2.00 lbs 45 Degree 24 **ACG** 5710641 2.30 lbs 45 Degree 24 **PVDF** 58106__ 2.30 lbs 45 Degree WEIGHT **GAUGE FINISH** PRODUCT NO. **TYPE** 6" X 4" ELBOW 26 **ACG** 5510441 2.00 lbs 95 Degree 26 MS Colorfast45® 55104__ 2.00 lbs 95 Degree 26 **PVDF** 56104__ 2.00 lbs 95 Degree С 24 5710441 95 Degree **ACG** 3.00 lbs 24 **PVDF** 3.00 lbs 95 Degree 58104__ **ACG** 5510841 2.00 lbs 26 45 Degree 55108__ 26 MS Colorfast45® 2.00 lbs 45 Degree 26 **PVDF** 2.00 lbs 56108__ 45 Degree 45 Degree 24 **ACG** 5710841 3.00 lbs 24 **PVDF** 3.00 lbs 45 Degree 58108__

TT3 metal sales


PBR-PANEL	FLASH	ING PROFIL	.ES		
PEAK	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
5" X*	26 26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF	5502241 5502441 55022 55024 56022 56024	8.25 lbs 16.50 lbs 8.25 lbs 16.50 lbs 8.25 lbs 16.50 lbs	10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3"
Hem 3/8"	24 24 24 24	ACG ACG PVDF PVDF	5702241 5702441 58022 58024	9.95 lbs 19.90 lbs 9.95 lbs 19.90 lbs	10'-2" 20'-3" 10'-2" 20'-3"
SCULPTURED HIGH SIDE EAVE	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
Hem X* 3 ¹ / ₂ " 150° 3 ¹ / ₂ "	26 26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF	5502241 5502441 55022 55024 56022 56024	8.25 lbs 16.50 lbs 8.25 lbs 16.50 lbs 8.25 lbs 16.50 lbs 9.95 lbs	10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3"
2"	24 24 24	ACG PVDF PVDF	5702441 58022 58024	19.90 lbs 9.95 lbs 19.90 lbs	20'-3" 10'-2" 20'-3"
RAKE	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
Hem 13/4" C	26 26 26	ACG MS Colorfast45® PVDF	5590441 55904 56904	8.10 lbs 8.10 lbs 8.10 lbs	10'-2" 10'-2" 10'-2"
5" 5" -5/8" Hem	24 24	ACG PVDF	5790441 59904	10.80 lbs 10.80 lbs	10'-2" 10'-2"
SCULPTURED RAKE	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
Hem 13/4" 6" C 31/2" 150°	26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF	5591141 5591241 55911 55912 56911 56912	13.80 lbs 27.60 lbs 13.80 lbs 27.60 lbs 13.80 lbs 27.60 lbs	10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3"
105° / 3 ¹ / ₂ " 2" - 2" Hem	24 24 24 24	ACG ACG PVDF PVDF	5791141 5791241 58911 58912	17.70 lbs 35.40 lbs 17.70 lbs 35.40 lbs	10'-2" 20'-3" 10'-2" 20'-3"
SCULPTURED RAKE END	GAUGE	FINISH	PRODUCT NO.	WEIGHT	
31/2" 105° 31/2" 105° 105° 105°	26 26 26 24 24	ACG MS Colorfast45® PVDF ACG PVDF	5504641 55046 56046 5704641 58046	.15 lbs .15 lbs .15 lbs .18 lbs .18 lbs	
10 © Metal Sales Manufa	cturing Corporati	on / Subject to change wit	hout notice 12/11	MS.	netal sales

PBR-PANEL	FLASHING PROFILES				
RAKEWALL	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
	26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF	5590241 5590341 55902 55903 56902 56903	7.20 lbs 14.40 lbs 7.20 lbs 14.40 lbs 7.20 lbs 14.40 lbs	10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3"
13/4" Hem	24 24 24 24	ACG ACG PVDF PVDF	5790241 5790341 58902 58903	9.60 lbs 19.20 lbs 9.60 lbs 19.20 lbs	10'-2" 20'-3" 10'-2" 20'-3"
PITCH BREAK	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
4"	26 26 26	ACG MS Colorfast45® PVDF	5504841 55048 56048	6.90 lbs 6.90 lbs 6.90 lbs	10'-2" 10'-2" 10'-2"
6".	24 24	ACG PVDF	5704841 59048	8.30 lbs 8.30 lbs	10'-2" 10'-2"
Hem					
COUNTER FLASHING	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
1"C	26 26 26	ACG MS Colorfast45® PVDF	5505241 55052 56052	2.75 lbs 2.75 lbs 2.75 lbs	10'-2" 10'-2" 10'-2"
<u> </u>	24	ACG	5705241	3.35 lbs	10'-2"
3/4"	24	PVDF	59052	3.35 lbs	10'-2"
3/4"					
REGLET FLASHING	24 GAUGE	PVDF FINISH	59052 PRODUCT NO.	3.35 lbs	10'-2"
REGLET FLASHING C 1/2" -1" -1					
REGLET FLASHING C 1/2" -1" -1 Hem	GAUGE 26 26	FINISH ACG MS Colorfast45®	PRODUCT NO. 5505441 55054	2.65 lbs 2.65 lbs	LENGTH 10'-2" 10'-2"
C	26 26 26 26 24 24	ACG MS Colorfast45® PVDF ACG PVDF	5505441 55054 56054 5705441 59054	2.65 lbs 2.65 lbs 2.65 lbs 2.65 lbs 3.20 lbs 3.20 lbs	10'-2" 10'-2" 10'-2" 10'-2" 10'-2"
C 1/2" 2" 2"	GAUGE 26 26 26 26	FINISH ACG MS Colorfast45® PVDF ACG	PRODUCT NO. 5505441 55054 56054 5705441	2.65 lbs 2.65 lbs 2.65 lbs 2.65 lbs 3.20 lbs	10'-2" 10'-2" 10'-2" 10'-2"
C	26 26 26 26 24 24	ACG MS Colorfast45® PVDF ACG PVDF	5505441 55054 56054 5705441 59054	2.65 lbs 2.65 lbs 2.65 lbs 2.65 lbs 3.20 lbs 3.20 lbs	10'-2" 10'-2" 10'-2" 10'-2" 10'-2"
C 11/2" 2" Hem GRAVEL STOP	26 26 26 24 24 24 24 GAUGE 26 26 26 26 26	ACG MS Colorfast45® PVDF ACG PVDF ACG ACG MS Colorfast45® MS Colorfast45® PVDF	PRODUCT NO. 5505441 55054 56054 56054 5705441 59054 PRODUCT NO. 5503041 5503241 55030 55032 56030	2.65 lbs 2.65 lbs 2.65 lbs 3.20 lbs 3.20 lbs 3.20 lbs 4.50 lbs 7.25 lbs 14.50 lbs 7.25 lbs	10'-2" 10'-2" 10'-2" 10'-2" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2"


PBR-PANEL FLASHING PROFILES SCULPTURED PEAK BOX 26 ACG 5596341 6.00 lbs 26 MS Colorfast45® 55963 6.00 lbs

SCOLF I ORED PEAR BOX
3 ¹ / ₂ " C

		RODGE RO	
26	ACG	5596341	6.00 lbs
26	MS Colorfast45®	55963	6.00 lbs
26	PVDF	56963	6.00 lbs
24	ACG	5796341	7.00 lbs
24	PVDF	59963	7.00 lbs



GAUGE	FINISH	PRODUCT NO.	WEIGHT	SIDE
26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF	5596441 5596241 55964 55962 56964	7.00 lbs 7.00 lbs 7.00 lbs 7.00 lbs 7.00 lbs	Left Right Left Right Left
26 24 24 24 24 24	PVDF ACG ACG PVDF PVDF	56962 5796441 5796241 58964 58962	7.00 lbs 8.00 lbs 8.00 lbs 8.00 lbs 8.00 lbs	Right Left Right Left Right



R-PANEL JAMB

GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
26	ACG	5596641	3.00 lbs	7'-3"
26	ACG	5520841	4.20 lbs	10'-2"
26	ACG	5596741	5.80 lbs	14'-2"
26	MS Colorfast45®	55966	3.00 lbs	7'-3"
26	MS Colorfast45®	55208	4.20 lbs	10'-2"
26	MS Colorfast45®	55967	5.80 lbs	14'-2"
26	PVDF	56966	3.00 lbs	7'-3"
26	PVDF	56208	4.20 lbs	10'-2"
26	PVDF	56967	5.80 lbs	14'-2"
24	ACG	5796641	3.60 lbs	7'-3"
24	ACG	5720841	5.00 lbs	10'-2"
24	ACG	5796741	7.00 lbs	14'-2"
24	PVDF	58966	3.60 lbs	7'-3"
24	PVDF	58208	5.00 lbs	10'-2"
24	PVDF	58967	7.00 lbs	14'-2"

\top	 1"
1 ³ / ₈ "	c
	35/8"

C-CLOSURE

GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
26 26 26 24 24 24	ACG MS Colorfast45® PVDF ACG PVDF	5520641 55206 56206 5720641 58206	4.00 lbs 4.00 lbs 4.00 lbs 5.00 lbs 5.00 lbs	10'-2" 10'-2" 10'-2" 10'-2" 10'-2"

PBR-PANEL FLASHING PROFILES

PBR-PANEL	FLASHING PROFILES				
PBR-PANEL OUTSIDE CORNER	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
1 ³ / ₄ "	26 26 26 26 26 26 26 26 26	ACG ACG ACG MS Colorfast45® MS Colorfast45® MS Colorfast45® PVDF PVDF PVDF	5591441 5591541 5591641 55914 55915 55916 56914 56915 56916	9.30 lbs 13.05 lbs 18.60 lbs 9.30 lbs 13.05 lbs 18.60 lbs 9.30 lbs 13.05 lbs 18.60 lbs	10'-2" 14'-2" 20'-3" 10'-2" 14'-2" 20'-3" 10'-2" 14'-2" 20'-3"
1 ³ / ₄ " Hem	24 24 24 24 24 24	ACG ACG ACG PVDF PVDF PVDF	5791441 5791541 5791641 58914 58915 58916	11.70 lbs 16.20 lbs 23.40 lbs 11.70 lbs 16.20 lbs 23.40 lbs	10'-2" 14'-2" 20'-3" 10'-2" 14'-2" 20'-3"
PBR-PANEL INSIDE CORNER	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
1 ³ / ₄ " 4" C	26 26 26 26 26 26 26 26 26 26	ACG ACG ACG MS Colorfast45® MS Colorfast45® MS Colorfast45® PVDF PVDF PVDF	5591741 5591841 5591941 55917 55918 55919 56917 56918 56919	9.30 lbs 13.05 lbs 18.60 lbs 9.30 lbs 13.05 lbs 18.60 lbs 9.30 lbs 13.05 lbs 18.60 lbs	10'-2" 14'-2" 20'-3" 10'-2" 14'-2" 20'-3" 10'-2" 14'-2" 20'-3"
Hem 5/8"	24 24	ACG PVDF	5791741 58917	11.70 lbs 11.70 lbs	10'-2" 10'-2"
OUTSIDE CORNER	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
OUTSIDE CORNER C 51/2" 51/2"	26 26 26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF ACG ACG	5513241 5513641 55132 55136 56132 56136 5713241 5713641	7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 10.20 lbs 20.40 lbs	10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3"
5 ¹ / ₂ " C	26 26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF	5513241 5513641 55132 55136 56132 56136 5713241	7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 10.20 lbs	10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3"
5 ¹ / ₂ " C	26 26 26 26 26 26 26 24 24 24	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF ACG ACG PVDF	5513241 5513641 55132 55136 56132 56136 5713241 5713641 58132	7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 10.20 lbs 20.40 lbs 10.20 lbs	10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2"
51/2" INSIDE CORNER 51/2"	26 26 26 26 26 26 24 24 24 24 24 24 26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF ACG ACG PVDF PVDF FINISH ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF	5513241 5513641 55132 55136 55136 56136 56136 5713241 5713641 58132 58136 PRODUCT NO. 5512641 5513041 55126 55130 56126 56130 56130	7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 10.20 lbs 20.40 lbs 10.20 lbs 20.40 lbs WEIGHT 7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 15.40 lbs	10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3"
INSIDE CORNER	26 26 26 26 26 26 24 24 24 24 24 24 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF ACG ACG PVDF PVDF FINISH ACG ACG MS Colorfast45® MS Colorfast45® PVDF	5513241 5513641 55132 55136 55136 56132 56136 5713241 5713641 58132 58136 PRODUCT NO. 5512641 5513041 55126 55130 56126 56126	7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 15.40 lbs 10.20 lbs 20.40 lbs 20.40 lbs WEIGHT 7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 7.70 lbs 15.40 lbs 7.70 lbs	10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2" 20'-3" 10'-2"


PBR-PANEL	FLASHING PROFILES				
1-1/4" BASE	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
2 ⁵ /8"	26 26 26	ACG MS Colorfast45® PVDF	5513841 55138 56138	3.25 lbs 3.25 lbs 3.25 lbs	10'-2" 10'-2" 10'-2"
	24 24	ACG PVDF	5713841 58138	4.40 lbs 4.40 lbs	10'-2" 10'-2"
1.5" SILL/HEAD	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
2 ¹ / ₂ " —1 ¹ / ₂ "—	26 26 26	ACG MS Colorfast45® PVDF	5511441 55114 56114	5.20 lbs 5.20 lbs 5.20 lbs	10'-2" 10'-2" 10'-2"
1"	24 24	ACG PVDF	5711441 58114	6.30 lbs 6.30 lbs	10'-2" 10'-2"
1.5" SILL TO SOFFIT	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
2 ¹ / ₂ "	26 26 26	ACG MS Colorfast45® PVDF	5511841 55118 56118	7.20 lbs 7.20 lbs 7.20 lbs	10'-2" 10'-2" 10'-2"
3/8" 1/2" 1/2" 43/4"	24 24	ACG PVDF	5711841 58118	8.75 lbs 8.75 lbs	10'-2" 10'-2"
HEAD CHANNEL	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
2 ¹ / ₂ " - 1 ³ / ₈ " - 1"	26 26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF	5596041 5512241 55960 55122 56960 56122	1.60 lbs 4.50 lbs 1.60 lbs 4.50 lbs 1.60 lbs 4.50 lbs	3'-6" 10'-2" 3'-6" 10'-2" 3'-6" 10'-2"
c → `	24 24	ACG PVDF	5712241 58122	5.15 lbs 5.15 lbs	10'-2" 10'-2"
HEAD/JAMB COVER	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
2 ⁷ / ₈ "	26 26 26 26 26 26 26 26	ACG ACG MS Colorfast45® MS Colorfast45® PVDF PVDF ACG PVDF	5512441 5596141 55124 55961 56124 56961 5712441 58124	9.25 lbs 12.25 lbs 9.25 lbs 12.25 lbs 9.25 lbs 12.25 lbs 11.00 lbs 11.00 lbs	10'-2" 14'-2" 10'-2" 14'-2" 10'-2" 10'-2"
COPING	GAUGE	FINISH	PRODUCT NO.	WEIGHT	LENGTH
C 10" 4" 4" Hem	26 26 26 24 24	ACG MS Colorfast45® PVDF ACG ACG	5502641 55026 56026 5702641 5702841	12.20 lbs 12.20 lbs 12.20 lbs 15.35 lbs 30.70 lbs	10'-2" 10'-2" 10'-2" 10'-2" 14'-2"
5/ ₈ ii © Metal Sales Manufa	24 24 acturing Corporation	PVDF PVDF on / Subject to change wit	58026 58028	15.35 lbs 30.70 lbs	10'-2" 14'-2" netal sales

PBR-PANEL	ACCESSORIES				
PBR-PANEL CLOSURE	SIZE	TYPE	PRODUCT NO.	WT/100	
Outside Closure	1" x 3'-0"	Polyethylene Foam Glued	6460699	9.00 lbs	
Inside Closure	1" x 3'-0"	Polyethylene Foam Glued	6460800	7.00 lbs	
UNIVERSAL CLOSURE	SIZE	TYPE	PRODUCT NO.	WT/100	COLOR
	1" x 1 ¹ / ₂ " x 50'	Polyethylene Foam	6411100	4.00 lbs	Grey
VERSA VENT	SIZE	TYPE	PRODUCT NO.	WT/10	CTN QTY
White the same of	1" x 1 ¹ / ₂ " x 10'	Vented Foam			10
PROFILE VENT	SIZE	TYPE	PRODUCT NO.	WEIGHT	CTN QTY
Profile Vent The albet view out to til	3" x 50'	Vented Foam			2
SINGLE BEAD TAPE SEALANT	SIZE	TYPE	PRODUCT NO.	WT/CTN	CTN QTY
	⁷ /8" x ³ / ₁₆ " x 25'	Butyl	6404099	40.00 lbs	48 Rolls
TUBE SEALANT	SIZE	TYPE	PRODUCT NO.	WT/CTN	CTN QTY
	10.3 oz 10.3 oz 10.3 oz	Urethane White Urethane Bronze Urethane Grey	6402830 6402999 6402829	30.00 lbs 30.00 lbs 30.00 lbs	30 Tubes 30 Tubes 30 Tubes
metal sales © M	letal Sales Manufa	cturing Corporation / Sub	oject to change without	notice 12/11	15

ACCESSORIES

SIZE

LIGHT TRANSMITTING PANEL



SIZE	S.F. WEIGHT	PRODUCT NO.	WT/PC	COLOR
3'-0" X 12'-0"	8 oz	6190030	21.00 lbs	White

TOUCH-UP PAINT



SIZE	TYPE	PRODUCT NO.	WEIGHT	
Pint	MS Colorfast45®	66004	1.60 lbs	
Pint	PVDF	66010	1.60 lbs	
2 oz Bottle	PVDF	66005	.15 lbs	

PRODUCT NO. BASE DIA.

WEIGHT

RUBBER ROOF DECK FLASHING


Rubber Roof Jack Round Base



#1 Flasher	Rubber	68501*	¹ /4" - 2"	3.00 lbs
#2 Flasher	Rubber	68502 *	1 ³ / ₄ " - 3 ¹ / ₄ "	3.00 lbs
#3 Flasher	Rubber	68503 *	¹ /4" - 5"	3.00 lbs
#4 Flasher	Rubber	68504 *	3" - 6 ¹ / ₄ "	3.00 lbs
#5 Flasher	Rubber	68505 *	41/4" - 71/2"	5.00 lbs
#6 Flasher	Rubber	68506 *	5" - 9"	9.00 lbs
#7 Flasher	Rubber	68507 *	6" - 11"	11.00 lbs
#8 Flasher	Rubber	68508 *	7" - 13"	13.00 lbs
#9 Flasher	Rubber	68509 *	10" - 19"	13.00 lbs
*Special order of	colors: 93=Brown: 94=Gre	 een: 95=Red: 96=Blue:	97=White: 98=Gr	ev: 99=Black

#1 Flasher	HT Silicone	6850011	¹ / ₄ " - 2"	3.00 lbs
#2 Flasher	HT Silicone	6850012	13/4" - 31/4"	3.00 lbs
#3 Flasher	HT Silicone	6850013	¹ /4" - 5"	3.00 lbs
#4 Flasher	HT Silicone	6850014	3" - 6 ¹ / ₄ "	3.00 lbs
#5 Flasher	HT Silicone	6850015	41/4" - 71/2"	5.00 lbs
#6 Flasher	HT Silicone	6850016	5" - 9"	9.00 lbs
#7 Flasher	HT Silicone	6850017	6" - 11"	11.00 lbs
#8 Flasher	HT Silicone	6850018	7" - 13"	13.00 lbs
#9 Flasher	HT Silicone	6850019	10" - 19"	13.00 lbs
1 Masterflash	Retrofit HT	6850060	¹ / ₄ " - 2"	4.00 lbs
2 Masterflash	Retrofit HT	6850061	1¹/₄" - 3"	4.00 lbs
3 Masterflash	Retrofit HT	6850062	¹ / ₄ " - 4"	4.00 lbs

Retro Roof Jack Square Base



GRAY ROUND RETRO ROOF JACK										
#1 Masterflash #2 Masterflash 0#3 Masterflash	Retrofit E.P.D.M Retrofit E.P.D.M Retrofit E.P.D.M	6850073 6850074 6850075	1/4" - 2" 11/4" - 3" 1/4" - 4"	4.00 lbs 4.00 lbs 4.00 lbs						
	BLACK ROL	JND RETRO ROOF	JACK							
#1 Masterflash #2 Masterflash #3 Masterflash	Retrofit E.P.D.M Retrofit E.P.D.M Retrofit E.P.D.M	6850070 6850071 6850072	¹ / ₄ " - 2" 1 ¹ / ₄ " - 3" ¹ / ₄ " - 4"	4.00 lbs 4.00 lbs 4.00 lbs						

BLACK SQUARE RETRO ROOF JACK										
#1 Masterflash Retrofit E.P.D.M 6850046 1/4" - 2" 4.00 lb #2 Masterflash Retrofit E.P.D.M 6850047 11/4" - 3" 4.00 lb #3 Masterflash Retrofit E.P.D.M 6850048 1/4" - 4" 4.00 lb	s									

PBR-PANEL **ACCESSORIES PROFILES TYPE WEIGHT** PRODUCT NO. **PBR-PANEL SHEAR** PBR-Panel 85.00 lbs Straight 6536799 and R-Panel WT/ROLL SIZE PRODUCT NO. **COVERAGE TYPE** ms-HT UNDERLAYMENT 36" x 75'-0" Peel-n-Stick 44.00 lbs 4121200 2 Squares/Roll High Temp Underlayment SIZE TYPE PRODUCT NO. WT/ROLL **COVERAGE UNDERLAYMENT PRIMER** 6600000 5 Gallon Liquid 44.00 lbs 100-125 sf per gallon depending on substrate **CONTENTS** SIZE PRODUCT NO. WT/ROLL **COVERAGE ALSAN KIT** Kit 1 Gallon Alsan 4130300 10.00 lbs 25 sf per 1 Roll Poly Fleece gallon Tools depending on 1 Instructional Video weather temperature SIZE PRODUCT NO. WT/ROLL TYPE **QTY POLY FLEECE ROLL** 4" x 50' Poly Fleece 4130500 .30 lbs 1 Roll 6" x 50' Poly Fleece 4130400 .50 lbs 1 Roll


🏿 metal sales

PBR-PANEL	FASTENERS								
POP RIVET	SIZE	TYPE	PRODUCT NO.	FINISH	WT/250				
	¹ /8" X ³ / ₁₆ " ¹ /8" X ³ / ₁₆ "	Aluminum Aluminum	8240901 82409	Unpainted Painted*	.75 lbs .75 lbs				
*Limited stocked colors	70 % 710	, tariii arii	02100	Tunted	.70100				
WOODSCREW	SIZE	TYPE	PRODUCT NO.	FINISH	WT/250				
WOODSCREW	#10-14 x 1"	А	82101	Painted	4.30 lbs				
1/4"	#10-14 x 1 ¹ / ₂ "	Α	82103	Painted	5.50 lbs				
~~ujj	#10-14 x 2"	Α	82104	Painted	6.70 lbs				
WOODSCREW XL	SIZE	TYPE	PRODUCT NO.	FINISH	WT/250				
	#10-14 x 1"	A	8212100	XL	6.50 lbs				
3/8"	#10-14 x 1 ¹ / ₂ "	Α	8212300	XL	7.50 lbs				
	XL Fasteners are reco	mmended for use wit	h bare galvalume panels an	d flashings.					
PANCAKE HEAD WOODSCREW	SIZE	TYPE	PRODUCT NO.	FINISH	WT/250				
\cap	#10-12 x 1"	Α	8243100	Plated	6.50 lbs				
THE THE TRANSPORT OF THE PROPERTY OF THE PROPE									
U									
SELF DRILLER (SD)	SIZE	TYPE	PRODUCT NO.	FINISH	WT/250				
— <u> </u>	#12-14 x 1"	Driller	82201	Painted	7.80 lbs				
3/8"	#12-14 x 1 ¹ / ₂ " #12-14 x 2"	Driller Driller	82203 82204	Painted Painted	8.50 lbs 11.00 lbs				
V -									
SELF DRILLER XL	SIZE	TYPE	PRODUCT NO.	FINISH	WT/250				
∕ TL	#12-14 x 1"	Driller	8235300	XL	12.00 lbs				
3/8"	#12-14 x 1 ¹ / ₂ " #12-14 x 2"	Driller Driller	8235400 8235500	XL XL	13.00 lbs 14.00 lbs				
	XL Fasteners are rec	ommended for use w	ith bare galvalume panels a	nd flashings.					
PANCAKE HEAD SELF DRILLER	SIZE	TYPE	PRODUCT NO.	FINISH	WT/250				
	#10-16 x 1"	Driller	8242100	XL	6.50 lbs				
	#10 10 X 1	Dillici	0242100	ΛL	0.00 103				
	SIZE	TYPE	PRODUCT NO.	FINISH	WT/250				
STITCH									
1/4"	¹ / ₄ " -14 x ⁷ / ₈ "	Stitch	82348	Painted	7.70 lbs				
STITCH XL	SIZE	TYPE	PRODUCT NO.	FINISH	WT/250				
	1/ " 44 × 7/ "	Stitch	8236800	XL	10.50 lbs				
— — —	¹ / ₄ " -14 x ⁷ / ₈ "	Cittori							
1/4"			h bare galvalume panels an						

PBR-PANEL FASTENER PHYSICAL PROPERTIES

I DIX-I ANLL	/ (O E 1		SICAL I NOI LIVILO					
FASTENER	SIZE	HEAD DIA/TYPE	THREAD DIA. O.D.	THREAD DIA. I.D.	MIN TENSILE	MIN. TORSIONAL	NOM. SHEAR	
WOODSCREW	#10-14	1/4" HWH	.190200	.128133				
WOODSCREW XL	#10-14	1/4" HWH	.190200	.128133				
PANCAKE HEAD WOODSCREW								
SELF DRILLER	#12-14	5/16" HWH	.209215	.157165	3446	128	2100	
SELF DRILLER XL	#12-14	5/16" HWH	.209215	.157165	3446	130	2100	
PANCAKE HEAD SELF DRILLER								
STITCH	¹ /4 -14	5/16" HWH	.240246	.185192				
STITCH XL	¹/4 -14	5/16" HWH	.240246	.185192				

UL 580 WIND UPLIFT INFORMATION



PBR-PANEL

Construction No. 161 November 02, 2001 Uplift - Class 90 Fire Not Investigated 1. Metal Roof Deck PanNo. 26 MSG min gauge coated steel. Panels continuous over two or more spans. End laps to occur over purlins with panels overlapped a min of 4 in. with lap centered over purlin web. A line of tape sealant may be used at panel side and end laps.

Metal Sales Manufacturing Corporation "R-Panel" "PBR-Panel".

2. Panel Fasteners For panel to panel and panel to purlin connections to be No. 12-14 by 1 in. self-drilling, self-tapping, hex head, plated steel screws with a 5/8 in. OD formed steel washer and a neoprene sealing washer.

As alternate Fasteners - For panel to purlin connections, 1/4 - 14 HHAB self-tapping, plating steel screws, with a separate 5/8 in. OD dome shaped steel washer and a neoprene sealing washer may be used.

Or: No. 14-10HHA, self-tapping, plating steel screws, with a separate, 5/8 in. OD dome shaped steel washer and a neoprene sealing washer may be used.

Spacing, for panel - to - purlin connections to be 12 in. on center beginning 2 - 1/2 in. from center line on one side of each major rib. Spacing at end lap to be in a 5 - 7 - 5 - 7 in. pattern beginning 2 - 1/2 in. from the center line on both sides of each major rib.

Fastener for panel to purlin connection to be 1-1/4 in. long when insulation (Item 3) is greater that 4-1/2 in. Spacing for panel - to - panel connections to be 20 in. on center with a fastener located in line with the purlin fasteners.


- 3. Insulation (Optional) Any compressible blanket insulation 6 in. max thickness before compression.
- 4. Purlin No. 16 MSG min gauge steel (50,000 psi min yield).
- Lateral Bracing (Not shown) As required.
 Refer to General Information, Roof Deck Construction, (Roofing Materials and Systems Directory) for items not evaluated.
 - * Bearing the UL Classification Mark.





SECTION PROPERTIES

R-PANEL




SECTION PROPERTIES

ALLOWABLE UNIFORM LOADS PSF (3 or More Equal Spans)

Ga	Width	Yield	rield Weight	Top in Cor	•	Bottom in Compression			· · l nad						Outward Load					
Ga. (in.)	(in.)	KSI	KSI	PSF	lxx In⁴/ft	Sxx In³/ft	lxx In⁴/ft	Sxx In³/ft	2'	3'	4'	5'	6'	7'	2'	3'	4'	5'	6'	7'
26	36"	80	0.87	0.0350	0.0348	0.0293	0.0439	235	119	71	47	27	17	270	132	77	50	35	26	
24	36"	50	1.13	0.0543	0.0558	0.0427	0.0595	316	147	85	55	38	27	398	185	106	68	48	35	
22	36"	50	1.45	0.0767	0.0814	0.0600	0.0790	434	199	113	73	51	37	594	273	155	100	70	51	

- 1. Theoretical Section Properties have been calculated per AISI 2007 "North American Specification for the Design of Cold-Formed Steel Structural Members". Ixx & Sxx are effective section properties for deflection and bending.
- 2. Allowable load is calculated in accordance with AISI 2007 specification considering: bending, shear, combined bending and shear, deflection and ASTM E 1592 testing for 24 ga and 22 ga. Allowable load is base on 3 or more equal span condition. Allowable load does not consider panel weight, web crippling, fasteners / support conditions or testing for 26 gauge.
- 3. Deflection consideration is limited by a maximum deflection ratio of L/180 of span.
- 4. Allowable loads do not include a 1/3 stress increase in uplift.

PBR-PANEL



SECTION PROPERTIES

ALLOWABLE UNIFORM LIVE LOADS PSF (3 or More Equal Spans)

| | Width | Yield | Yield | Yield | Yield | Yield | Yield | Yield | Yield | Yield | Yield
 | Weight
 | Top in Cor
 | mpression | Bottom in C
 | Bottom in Compression | | Inward (Gravity / Deflection) |
 | | | | Outward Uplift (Stress) | | | | |
|------|-----------------|---------------------------|-------------------------------------|---|--|---|--|--|---|---
--

--
---	--
--	---
}a.∣	
 | Load
 |
 | | ad
 | | | |
 | | | | | | | | |
| | (111.) | | . | In ⁴ /ft | In³/ft | _ | | 2' | 3' | 4' | 5'
 | 6'
 | 7'
 | 2' | 3'
 | 4' | 5' | 6' | 7'
 | | | | | | | | |
| 26 | 36" | 80 | 0.84 | 0.0367 | 0.0367 | 0.0317 | 0.0458 | 261 | 129 | 76 | 49
 | 35
 | 23
 | 223 | 107
 | 62 | 40 | 28 | 21
 | | | | | | | | |
| 24 | 36" | 50 | 1.09 | 0.0560 | 0.0579 | 0.0457 | 0.0613 | 330 | 153 | 88 | 57
 | 39
 | 29
 | 314 | 145
 | 83 | 53 | 37 | 27
 | | | | | | | | |
| 22 | 36" | 50 | 1.43 | 0.0800 | 0.0860 | 0.0633 | 0.0816 | 453 | 207 | 118 | 76
 | 53
 | 39
 | 474 | 218
 | 124 | 80 | 55 | 40
 | | | | | | | | |
| | ea.
26
24 | (in.)
26 36"
24 36" | (in.) KSI
26 36" 80
24 36" 50 | 6a. (in.) KSI PSF
26 36" 80 0.84
24 36" 50 1.09 | Ga. Width (in.) Yield KSI Weight PSF Ixx In ⁴ /ft 26 36" 80 0.84 0.0367 24 36" 50 1.09 0.0560 | Ga. (in.) KSI PSF Ixx In ⁴ /ft Sxx In ³ /ft 26 36" 80 0.84 0.0367 0.0367 24 36" 50 1.09 0.0560 0.0579 | Ga. Width (in.) Yield (in.) Weight PSF Ixx Ixx In4/ft Sxx Ixx In4/ft In3/ft In4/ft 26 36" 80 0.84 0.0367 0.0367 0.0317 24 36" 50 1.09 0.0560 0.0579 0.0457 | Ga. Width (in.) Yield (in.) Weight (in.) Ixx Sxx Ixx Sxx 1 x x | Ga. Width (in.) Yield (in.) Weight KSI IXX SXX IXX SXX 1n ⁴ /ft In ³ /ft In ⁴ /ft In ³ /ft In ⁴ /ft In ³ /ft 2' 26 36" 80 0.84 0.0367 0.0367 0.0317 0.0458 261 24 36" 50 1.09 0.0560 0.0579 0.0457 0.0613 330 | Ga. Width (in.) Yield (in.) Weight KSI IXX SXX IXX SXX 1n²/ft In³/ft In³/ft In⁴/ft In³/ft 2′ 3′ 26 36" 80 0.84 0.0367 0.0367 0.0317 0.0458 261 129 24 36" 50 1.09 0.0560 0.0579 0.0457 0.0613 330 153 | Ga. Width (in.) Yield (in.) Weight KSI IXX SXX IXX SXX IXX SXX IXX IXX </th <th>Ga. Width (in.) Yield (in.) Weight KSI IXX SXX IXX SXX IXX SXX IxX SXX IxX IxX SXX IxX IXX<!--</th--><th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Ixx<!--</th--><th>Ga. Width (in.) Yield (in.) Weight KSI IXX SXX IXX SXX IXX SXX In4/ft In3/ft In4/ft In4/ft</th><th>Ga. Width (in.) Yield (in.) Weight KSI IXX In4/ft Sxx In4/ft IxX In3/ft IxX In4/ft Sxx In4/ft IxX In3/ft IxX In3/ft<!--</th--><th>Ga. Width (in.) Yield (in.) Weight KSI IXX In4/ft Sxx In4/ft IxX In3/ft IxX In4/ft Sxx In4/ft IxX In3/ft IxX In3/ft<!--</th--><th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In4/ft</th><th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In4/ft</th><th>Ga. Width (in.) Yield (sin.) Weight (sin.) Ixx Sxx Ixx I</th></th></th></th></th> | Ga. Width (in.) Yield (in.) Weight KSI IXX SXX IXX SXX IXX SXX IxX SXX IxX IxX SXX IxX IXX </th <th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Ixx<!--</th--><th>Ga. Width (in.) Yield (in.) Weight KSI IXX SXX IXX SXX IXX SXX In4/ft In3/ft In4/ft In4/ft</th><th>Ga. Width (in.) Yield (in.) Weight KSI IXX In4/ft Sxx In4/ft IxX In3/ft IxX In4/ft Sxx In4/ft IxX In3/ft IxX In3/ft<!--</th--><th>Ga. Width (in.) Yield (in.) Weight KSI IXX In4/ft Sxx In4/ft IxX In3/ft IxX In4/ft Sxx In4/ft IxX In3/ft IxX In3/ft<!--</th--><th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In4/ft</th><th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In4/ft</th><th>Ga. Width (in.) Yield (sin.) Weight (sin.) Ixx Sxx Ixx I</th></th></th></th> | Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Ixx </th <th>Ga. Width (in.) Yield (in.) Weight KSI IXX SXX IXX SXX IXX SXX In4/ft In3/ft In4/ft In4/ft</th> <th>Ga. Width (in.) Yield (in.) Weight KSI IXX In4/ft Sxx In4/ft IxX In3/ft IxX In4/ft Sxx In4/ft IxX In3/ft IxX In3/ft<!--</th--><th>Ga. Width (in.) Yield (in.) Weight KSI IXX In4/ft Sxx In4/ft IxX In3/ft IxX In4/ft Sxx In4/ft IxX In3/ft IxX In3/ft<!--</th--><th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In4/ft</th><th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In4/ft</th><th>Ga. Width (in.) Yield (sin.) Weight (sin.) Ixx Sxx Ixx I</th></th></th> | Ga. Width (in.) Yield (in.) Weight KSI IXX SXX IXX SXX IXX SXX In4/ft In3/ft In4/ft In4/ft | Ga. Width (in.) Yield (in.) Weight KSI IXX In4/ft Sxx In4/ft IxX In3/ft IxX In4/ft Sxx In4/ft IxX In3/ft IxX In3/ft </th <th>Ga. Width (in.) Yield (in.) Weight KSI IXX In4/ft Sxx In4/ft IxX In3/ft IxX In4/ft Sxx In4/ft IxX In3/ft IxX In3/ft<!--</th--><th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In4/ft</th><th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In4/ft</th><th>Ga. Width (in.) Yield (sin.) Weight (sin.) Ixx Sxx Ixx I</th></th> | Ga. Width (in.) Yield (in.) Weight KSI IXX In4/ft Sxx In4/ft IxX In3/ft IxX In4/ft Sxx In4/ft IxX In3/ft IxX In3/ft </th <th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In4/ft</th> <th>Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In4/ft</th> <th>Ga. Width (in.) Yield (sin.) Weight (sin.) Ixx Sxx Ixx I</th> | Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In3/ft In4/ft In4/ft | Ga. Width (in.) Yield (in.) Weight KSI IXX Sxx Ixx Sxx Ixx Sxx In4/ft In3/ft In4/ft In4/ft In3/ft In4/ft In4/ft | Ga. Width (in.) Yield (sin.) Weight (sin.) Ixx Sxx Ixx I | | | | | | | | |

- 1. Theoretical Section Properties have been calculated per AISI 2007 "North American Specification for the Design of Cold-Formed Steel Structural Members". lxx & Sxx are effective section properties for deflection and bending.
- 2. Allowable load is calculated in accordance with AISI 2007 specification considering: bending, shear, combined bending and shear, deflection and ASTM E 1592 testing for 24 ga and 22 ga. Allowable load is base on 3 or more equal span condition. Allowable load does not consider panel weight, web crippling, fasteners / support conditions or testing for 26 gauge.
- 3. Deflection consideration is limited by a maximum deflection ratio of L/180 of span.
- 4. Allowable loads do not include a 1/3 stress increase in uplift.



HANDLING MATERIAL

RECEIVING MATERIAL

It is the responsibility of the installer to unload material from the delivery truck. The installer shall be responsible for providing suitable equipment for unloading of material from the truck.

After receiving material, check the condition of the material, and review the shipment against the shipping list to ensure all materials are accounted for. If damages or shortages are discovered, it should be noted on the Bill of Lading at the time of delivery. A claim should be made against the carrier as soon as possible. Metal Sales is not responsible for any damages or shortages unless they are documented in writing and presented to Metal Sales within 48 hours.

GENERAL HANDLING

Each bundle should be handled carefully to avoid being damaged. Care should be taken to prevent bending of the panel or abrasion to finish. Whenever possible, the bundle should remain crated until it is located in its place of storage. If bundles must be opened, we recommend you re-crate them before lifting. To avoid damage please lift the bundle at its center of gravity.


CAUTION

Improper loading and unloading of bundles and crates may result in bodily harm and/or material damage. Metal Sales is not responsible for bodily injuries and/or material damages resulting from improper loading and unloading.

MECHANICAL HANDLING

Forklift - A forklift may be used for panels up to 20'-0" long. Please make sure the forks are at their maximum separation. Do not transport open bundles. When transporting bundles across rough terrain, or over a longer distance, some means of supporting the panel load must be used.

Crane - A crane should be used when lifting panels with lengths greater than 20'-0". Please be sure to utilize a spreader bar to ensure the even distribution of the weight to the pick up points. As a rule when lifting panels, no more than 1/3 of the length of the panel should be left unsupported. Never use wire rope because this will damage the panels.







MANUAL HANDLING

When handling painted steel care should be taken to prevent scratching of material. Clean gloves should be worn at all times to prevent a reaction with salts found on bare skin. Installers should wear rubber sole shoes to keep from scuffing material while walking on the roof.


Handling of individual panels should be done carefully and properly to avoid bending or damaging. PBR-Panels should be carried by grasping the edge of the panel so that the PBR-Panel is vertical to the ground. The PBR-Panel should not be carried with the panel horizontal to the ground as this could cause the panel to buckle or bend in the center.

Normally individual panels can be handled by people placed every 6'-0" to 8'-0" along the length of the panel.






INCORRECT



GENERAL

Please inspect panels for moisture accumulation. If moisture has formed, the panels should be unbundled, wiped dry, and allowed to dry completely. Once dry, carefully re-stack the panels and loosely recover allowing for ample air circulation.

Bundled sheets should be stored high enough off of the ground to allow for air circulation and prevent contact with accumulating water. Elevate one end of the bundle to allow any moisture to run off the panels. Metal Sales recommends covering the bundle with a tarp. Do not use tight fitting plastic-type tarps as panel bundle covers. While they may provide protection from heavy downpours, they can also retard necessary ventilation and trap heat and moisture that may accelerate metal corrosion. If panels are to be stored in possible bad weather, we suggest they be stored inside. Extended storage of panels in a bundle is not recommended. **Under no circumstances should the panels be stored near or come in contact with salt water, corrosive chemicals, ash, or fumes generated or released inside the building or nearby plants, foundries, plating works, kilns, fertilizer, and wet or green lumber.**



FOOT TRAFFIC

Care of metal panels and flashings must be exercised throughout erection. Foot traffic can cause distortion of panel and damage to finish. Traffic over the installed system must be kept to an absolute minimum. Installers should wear rubber sole shoes to keep from scuffing material while walking on the roof.

When walking on the roof panels is unavoidable, walk only in the flats of the panel. Walking on the ribs can cause damage to the panels.

REQUIRED TOOLS

Standard required tools for field installation include:

- Screw Guns
- Magnetic Bits
- Metal Nibbler or Shear
- Tin Snips
- Tape Measure
- Hammer
- Chalk Line
- Power Drill
- Drill Bits
- Pop Rivet Gun
- Safety Goggles
- Gloves
- Ear Plugs
- Fall Protection



ROOF PREPARATION

CONDITION OF SUBSTRUCTURE

Metal Sales' panels are designed to be installed over open framing and/or directly over a wood substrate (minimum 5/8") with 30# felt moisture barrier (or an Ice and Water Shield when required by Local Building Codes).

Always check with local building codes prior to all installations for any additional requirements that may be specific to your area.

Galvanized and Galvalume panels should not be in contact with, or subject to, water runoff from copper, lead, or uncoated steel materials.

Condensate water from air conditioning units typically contains dissolved copper. This condensate should be discharged through a plastic pipe extended beyond the edge of the roof.

The roof should be inspected for any trapped moisture or structural damage such as bowing or sagging rafters and warped or loose roof purlins or solid decking. These areas should be repaired prior to installing new metal panels.

Prior to installation, make sure there are no nails or fasteners protruding from the roof framing or wood substrate which could damage the panels and impede the installation process.

When installed, panel distortion may occur if not applied over properly aligned and uniform substructure.


Whether installing over new or existing roof, the installer should check the roof deck for squareness before installing panels. Several methods can be used to verify squareness of the structure for proper installation of the panels.

METHOD "A" - One method for checking the roof for squareness is to measure diagonally across one slope of the roof from similar points at the ridge and eave and obtain the same dimension.

METHOD "B" - The 3-4-5 triangle system may also be used. To use this system, measure a point from the corner along the

edge of the roof at a module of three (3). Measure a point from the same corner along another edge at a module of four (4).

By measuring diagonally between the two points established, the dimension should be exactly a module of five (5) to have a square corner. Multiple uses of this system may be required to determine building squareness. If the endwall cannot be made square, the roof system cannot be installed as shown in these instructions.





FIELD CUTTING AND TOUCH-UP

FIELD CUTTING

Tin snips or a "nibbler" type electric tool are recommended for field cutting metal panels. Cutting the steel generates slivers or metal chips. These slivers and metal chips must be immediately removed from the panels because they will damage the finish and shorten the life of the product.

One method of preventing this problem is to flip the panels over when cutting. This allows the slivers and metal chips to be brushed from the back side and avoids damaging the paint on the top side of the panels.

When cutting metal panels and flashings, goggles must be worn for eye protection.

CAUTION

All product surfaces should be free of debris at all times. Installed surfaces should be wiped clean at the end of each work period. Never cut panels over metal surfaces.

Metal shavings will rust on the surface, voiding the warranty.

TOUCH-UP PAINT

All painted panels and flashings have a factory applied baked on finish. Handling and installing panels may result in some small scratches or nicks to the paint finish. Touch-up paint is available in matching colors from Metal Sales. It is recommended that a small brush be used to apply touch-up paint to those areas that are in need of repair. Touch-up paint does not have the superior chalk and fade resistance of the factory applied paint finish and will normally discolor at an accelerated rate. Aerosol paint should not be used because of the over-spray that may occur.





TOUCH-UP PAINT

VENTILATION

Proper design and installation of vapor barriers and ventilation systems are important to prevent condensation and the resulting problems of moisture damage and loss of insulation efficiency.

Condensation occurs when moisture laden air comes in contact with a surface temperature equal to or below the dew point of the air. This phenomenon creates problems that are not unique with metal buildings; these problems are common to all types of construction.

The underside of the metal roof on a typical metal building (no attic) should be protected from condensation by insulating with a faced insulation. This should reduce the potential of condensation forming on the underside of the panels.

On buildings that have an attic space or are being retrofitted with a metal roofing system, vents should be placed at both the eave and peak of the roof in order to prevent a buildup of moisture (humidity) in the attic space.

CARE AND MAINTENANCE

Though factory applied pre-painted finishes are very durable and will last many years, eventually it may be desirable to thoroughly clean or repaint them.


Dirt pickup may cause apparent discoloration of the paint when it has been exposed in some dirt-laden environments for long periods of time. In areas of strong sunlight, slight chalking may cause some change in appearance. A good cleaning will often restore the appearance of these buildings and render repainting unnecessary. An occasional light cleaning will help maintain a good appearance.

In many cases, simply washing the building with plain water using a hose or pressure sprayer will be adequate. In areas where heavy dirt deposits dull the surface, a cloth or soft bristle brush and solution of water and detergent ($\frac{1}{3}$ cup of laundry detergent per gallon of water for example) may be used. This should be followed by an adequate rinse of water. Do not use wire brushes, abrasives, or cleaning tools which will damage the coating surface.

Mildew may occur in areas subject to high humidity but is not normally a problem due to the high inherent mildew resistance of the baked finish that is used. To remove mildew along with the dirt, the following solution is recommended.

- ¹/₃ cup detergent (Tide[®] or equivalent)
- ²/₃ cup trisodium phosphate (Solex® or equivalent)
- 1 quart of 5% sodium hypochlorite solution (Clorox® or equivalent)
- 3 quarts of water

Strong solvents and abrasive type cleaners should be avoided. Most organic solvents are flammable and toxic and must be handled accordingly. When using a solvent, consult maintenance professionals and label instructions for proper handling and disposal of washings. If required, a mild solvent such as mineral spirits can be used to remove caulking compounds, oil, grease, tars, wax, and similar substances. Use a cloth dampened with mineral spirits and apply only to areas which are contaminated. Follow up the use of this mild solvent with detergent cleaning and rinsing.



FIELD CUTTING AND TOUCH-UP

FASTENER INSTALLATION TECHNIQUE

Recommended Tool Type - Use depth locating nose or adjustable clutch on screw gun to prevent over-drilling and strip out. **Do not use impact tools or runners.**

Seating the washer - Apply sufficient torque to seat the washer - do not overdrive the fastener.

	CORRECT Sealing material slightly visible at edge of metal washer. Assembly is watertight.	TOO LOOSE Sealing material is not visible; not enough compression to seal properly.	TOO TIGHT Metal washer deformed; sealing material pressed beyond washer edge.
SELF DRILLER			
WOODSCREW			

To prevent wobbling - Make sure fastener head is completely engaged in the socket. If the head does not go all the way in the socket - tap the magnet deeper into the socket to allow full head engagement. Metal chips will build up from drilling and should be removed from time to time.

Protect drill point - Push only hard enough on the screw gun to engage clutch. This prevents excess friction and burn out of the drill point. Correct pressure will allow screw to drill and tap without binding.

Drilling through sheet and insulation - Ease up on pressure when drilling through insulation to avoid striking the purlin or girt with the point - apply more pressure after drill point contacts purlin or girt.


Drilling through purlin overlaps - Drilling through lapped purlins requires extra care. Excessive voids between purlins sometimes damages drill points and two self-drillers might be necessary to complete the operation. It is sometimes advantageous to predrill.



DETAIL TABLE OF CONTENTS


NOTES

- As shown below with the number designations, install panel against the prevailing wind. Installing Wall Panels first then Roof Panels
- To minimize corrosion, siding panels should not be installed all the way to the ground.
- Siding panels should lap over the foundations or splash boards at least three inches.
- Make sure panels are square and plumb, to assure straight and proper alignment of the entire row of panels.
- For areas with high wind considerations, closer fastener spacing may be required.
- It is necessary to attach a temporary guide to the foundation to use as an alignment guide when installing siding panels.



#	ROOF PANEL DETAILS	PAGE(S)	#	ROOF PANEL DETAILS	PAGE(S)	
-	ms-HT Install	34	7	Rakewall	46	
1	Eave Flashing	35	8	Endwall	47	
-	Valley	36	9	Ridge	48	
3	Roof Panel Install	37-38	10	Sculptured Gutter	49	
4	Endlap	39	#	WALL PANEL DETAILS	PAGE(S)	
5	Light Transmitting Panels	40	11	Outside Corner	50	
-	Rubber Roof Jack	41	12	Inside Corner	51	
-	Formed Ridge	42	13	Jamb	52	
-	Ridge/Hip Flashing	43	14	Base	53	
6	Sculptured Rake	44	17	Head Channel	54	
6	Rake	45	-	Gravel Stop	55	

ms-HT INSTALLATION



GENERAL INFORMATION

► Thickness: 40 mil
► Dimensions: 67' x 3'

► Gross Coverage: 200 ft²

► Net Coverage: 183 ft²
► Roll Weight: 43 lbs

► Installation Temperature: Above 50°


INSTALLATION STEPS

Note: ms-HT is a SBS modified bitumen self adhesive membrane intended to be used as a roofing underlayment. It has a slip resistant surface and will seal around penetrating fasteners.

- 1. Before installing the PBR-Panel roof it is recommended that a high-temperature underlayment (ms-HT) be installed on the solid substrate.
- 2. The ms-HT should extend over the edge of the roof surface a minimum of 2" on each side.
- 3. Start at the low side of the roof and roll out horizontally across the roof substructure.
- 4. If more than 1 roll is required as it is installed then the ms-HT must be endlapped a minimum of 6".
- 5. Once the bottom row is down and secure the next row is installed upslope of the first row. Lap the ms-HT a minimum of 3".



EAVE INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL FASTENING PATTERN

Open Framing Self Driller

Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"

Solid Wood Substrate




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing



Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"




INSTALLATION STEPS

Note: If you are installing an Eave Flashing where there is wall panel, the wall panel must be installed first.

- 1. Place the Eave Flashing at the eave and mark where the bottom of the Eave Flashing hits the wall panel.
- 2. Apply a row of Single Bead Tape Sealant along the top of the wall panel so that it is above your mark and below the fasteners at the top of the wall panel.
- 3. Place an Outside Closure or a Universal Closure over the Single Bead Tape Sealant.
- 4. Apply a second row of Single Bead Tape Sealant to the outside face of the wall closures along the eave.
- 5. Install the eave flashing flush against the wall panels, making sure to hide the closure, and fasten to the wall panel with a Stitch Fastener through the sealant and closure, at every major rib.
- 6. Fasten the top of the Eave Flashing to the roof deck with the appropriate Pancake Head Fastener, four feet on center to hold the Eave Flashing in place until the roof panels can be installed.



VALLEY INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL FASTENING PATTERN

Open Framing



Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"

Solid Wood Substrate




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing



Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"




INSTALLATION STEPS

Note: It is recommended that ms-HT be installed under the valley flashing for added moisture protection.

- 1. If two or more valley flashings are required, the valley must be installed working from eave to peak. If two or more Valley Flashings are required, then they must be lapped a minimum of 6" with two continuous beads of Tube Sealant between them.
- 2. Do not install fasteners through the valley lap.
- 3. Place the Valley Flashing upside down at the eave of the building and mark the cut line for the valley angle. Cut the Valley flashing with Turbo-Shears starting from each side, working towards the center "V". Mark the center "V" as shown to allow extra material to cap off the end of the valley flashing. Cut with Turbo-Shears and Tin Snips. Bend the cut tabs in to close the V.
- 4. Apply a three-eighths inch bead of Tube Sealant along the Eave Flashings and place the Valley Flashing down.
- 5. Fasten the Valley Flashing to the roof deck with pancake head woodscrews four feet on center, on each side



PANEL INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL END FASTENING PATTERN

Open Framing

Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"

Solid Wood Substrate




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"




INSTALLATION STEPS

- 1. If you're project has new or existing wall panels, you must consider adding additional overhang to your roof panels equal to the depth of the wall panels.
- 2. Turn the PBR Inside Closure over and attach Single Bead Tape Sealant to the underside. Place the PBR Inside Closure on top of the Eave Flashing. Install another row of Single Bead Tape Sealant to the top of the Inside Closure.
- 3. Make sure that the Inside Closure is square with the roof. Place the PBR-Panel over the Inside Closure.
- 4. The fastening pattern for roof panels at the panel ends, eave, gutter, ridge, or highside eave and at the endlap is as shown.
- 5. Fasteners at the ridge and highside eave are installed one inch from the end of the panels.
- 6. For certain building codes and state or county specifications, special fastener spacing may be required.
- 7. For the field of the panel the fastening pattern is as shown below.





ADDITIONAL PANEL INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL FASTENING PATTERN

Open Framing

Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"

Solid Wood Substrate




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing



Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"




INSTALLATION STEPS

Note:

- 1. Before you install the next PBR-Panel, Single Bead Tape Sealant must be placed on the under lap rib of the previous panel.
- 2. Place the second panel on top of the previously installed panel covering the Single Bead Tape Sealant. Make sure that it is flush and square at the eave with the previous panel.
- 3. Install a Stitch Fastener on top of the lapping rib one foot on center through the sealant and the underlap rib.
- 4. Repeat this process for the remaining panels.
- 5. If you come to a valley condition, lay the panel down at the valley and mark the panel ribs to be cut. Snap a chalk line for the diagonal cut of the panel three inches from the center of the valley.
- 6. A Universal Closure is used instead of an Inside Closure at the valley condition.
- 7. Be sure to clean any debris or excess sealant before continuing the next section of the roof.



ENDLAP INSTALLATION



SUBSTRATE FASTENER INFORMATION PBR-PANEL FASTENING PATTERN **Open Framing Solid Wood Substrate** 2X Wood Framing /4"-14 x ⁷/8" Stitch (1'-0" o.c.) Substrate Fastener mmm -> TITATI **Self Driller** Woodscrew Woodscrew #12-14 x 1" #10-14 x 1" #10-14 x 1" #12-14 x 1-1/2" #10-14 x 1-1/2" #10-14 x 1-1/2" Single Bead Tape Sealant (roof only) #10-14 x 2" #12-14 x 2" #10-14 x 2"


INSTALLATION STEPS

Note:

- 1. If more than one PBR Panel is required on a single panel run working eave to highside, then a panel endlap is required.
- 2. Start by installing all of the eave panels first. At the highside of the eave panels measure down three inches and apply a row of Single Bead Tape Sealant. Next apply another row of Single Bead Tape Sealant just above and below that first row.
- 3. Lap the highside panel over the eave panel a minimum of six inches.
- 4. Measure up the highside panel and install woodscrews with the correct fastening pattern so that the fastener goes through the middle row of the tape sealant and into the roof deck.



LIGHT TRANSMITTING PANEL INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL ENDLAP FASTENING PATTERN

Open Framing



#12-14 x 2"

Solid Wood Substrate




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing



#10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"



INSTALLATION STEPS


Note: Light Transmitting Panels require a minimum 6" lap at the low and high side of the panel.

- 1. Always install Light Transmitting Panels working from eave to ridge of the building for proper lapping.
- 2. After the Eave PBR-Panel is installed apply a row of Single bead Tape Sealant. Make sure that the Single Bead Tape Sealant is directly above your substrate member you are attaching to.
- 3. Place the low side of the Light Transmitting Panel over the Single Bead Tape Sealant.
- 4. Fasten the panels together with the substrate fastener, making sure the fastener goes through the middle of the Single Bead Tape Sealant and into the roof substrate member below.
- 5. Lap the highside panel over the Light Transmitting Panel a minimum of 6".
- 6. Measure up the highside panel and install woodscrews with the correct fastening pattern so that the fastener goes through the middle row of the Single Bead Tape Sealant and into the substrate member.

SAFETY NOTE: Never step, stand or walk on Light Transmitting Panels. They are not designed to carry point loading.



RUBBER ROOF JACK INSTALLATION




INSTALLATION STEPS

Note: Always abide by local plumbing codes when you're installing vent pipes

- 1. Areas around roof vents or rooftop units may show that corrosive fumes are emitted from a process within a building.
- 2. In the following example the procedures are for vent pipes six inches or less and not transmitting extremely hot or caustic materials.
- 3. The vent pipe must extend through the flat of the roof panel so that the Rubber Roof Jack does not block the flow of water. If the vent pipe extension cannot be raised directly into the minor ribs of the new roof panel, use elbows to offset the pipe.
- 4. Determine the size and length of the vent pipe to be raised.
- 5. Take the appropriate measurements for the pipe size and vent location, mark them on the PBR-Panel and cut the hole in the panel.
- 6. When cutting the hole in the panel for the penetration make the radius of the hole one half inch larger than the radius of the pipe. This will allow the panel to expand and contract around the penetration
- 7. Cut the top of the rubber roof jack so that it fits snug on the pipe. Slide the rubber roof jack onto the pipe all the way down until it is sitting on the roof panel.
- 8. If you are installing a square based rubber roof jack, make sure you turn it diamond shaped so the water runs around the side.
- 9. Lift the base of the rubber roof jack up so you can install tube sealant to the underside at the pipe.
- 10. Flip the rubber roof jack back down, flush with the panel
- 11. Bend up the base tabs of the rubber roof jack one side at a time and apply a bead of tube sealant. Repeat this with the other three sides of the rubber roof jack.
- 12. Attach the base of the rubber roof jack to the panel using stitch fasteners spaced 2" on center.
- 13. Apply tube sealant to the top of the rubber roof jack where it meets the pipe.



FORMED RIDGE INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL END FASTENING PATTERN

Open Framing



Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"

Solid Wood Substrate



Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing



Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

/ 1/4"-14 x ⁷/₅" Stitch (1'-0" o.c.) / Substrate Fastener

Single Bead Tape Sealant (roof only)


INSTALLATION STEPS

Note: It is critical that the panel ribs line up on both sides of the ridge before installing the Formed Ridge Flashing.

- 1. If you are using a Formed Ridge Flashing
- 2. If you using a Formed Ridge Condition then it should be installed before the Sculptured Rake.
- 3. Place the Formed Ridge Cover on top of the PBR roof panels at the ridge. Mark where the ridge flashing hits the PBR roof panels on both sides of the ridge.
- 4. Place a row of Single Bead Tape Sealant across the panel and over each panel rib on both sides of the ridge.
- 5. Fasten the Formed Ridge Flashing to the PBR roof panels with Woodscrew Fasteners, with the end fastening pattern.



RIDGE/HIP INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL END FASTENING PATTERN

Open Framing



Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"

Solid Wood Substrate



Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing



Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

-1/4"-14 x ⁷/s" Stitch (1'-0" o.c.) Substrate Fastener

Single Bead Tape Sealant (roof only)


INSTALLATION STEPS

Note: C-Closure is optional on Hip installation.

- 1. Place the 20" Ridge/Hip Cover on top of the PBR roof panels. Mark where the edge of the Ridge/Hip Cover hits the PBR roof panels, upslope of your mark and downslope of the end fasteners, place a row of Single Bead Tape Sealant across the panel and over each panel rib.
- 2. Place PBR Outside Closures on top of the Single Bead Tape Sealant.
- 3. Apply a second row of Single Bead Tape Sealant to the top of the PBR Outside Closures.
- 4. Fasten the Ridge/Hip Cover to the PBR roof panels through the PBR Outside Closures with Stitch Fasteners, one at every major rib.
- 5. Now fasten the top of the Pitch Break Flashing to the wall or behind the wall panel.
- 6. If two or more flashings are required lap the flashing over the previously installed flashing by a minimum of two inches. Place a two beads of tube sealant between the flashings and secure with pop rivets two and a half inches on center.



SCULPTURED RAKE INSTALLATION



SUBSTRATE FASTENER INFORMATION

Open Framing Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"




#10-14 x 2"



- 1. Before installing the Sculptured Rake Flashing the Rake Ends will need to be installed.
- 2. Place the Rake Ends into the end of the Sculptured Rake Flashing and fasten with Pop Rivets.
- Place the Sculptured Rake Flashing on the rake of the building and lightly mark where the bottom of the flashing hits the wall panel along the slope. Also mark where the edge of the Sculptured Rake rests on the roof panel.
- 4. Place a row of Single Bead Tape Sealant along the slope of the rake at the top of the wall panel so that it is behind the Sculptured Rake Flashing.
- 5. Apply a Universal Closure over the Single Bead Tape Sealant. Press firmly into place.
- 6. For slopes up to three to twelve a PBR Outside Closure can be used for PBR wall panels.
- 7. The Universal closure will act as a barrier to keep insects and debris from entering the building.
- 8. Apply a second row of Single Bead Tape Sealant to the face of the Universal Closure. Also apply a row of Single Bead Tape Sealant to the roof panels inside of the marks made.
- 9. Install the Sculptured Rake Flashing flush against the wall panels, making sure to hide the Universal Closure. Fasten through the closure to the wall panel with a Stitch Fastener at every major rib.
- 10. Fasten the Sculptured Rake Flashing to the PBR roof panel with a Stitch fastener 1'-0" o.c..



SCULPTURED PEAK INSTALLATION




SUBSTRATE FASTENER INFORMATION

PBR-PANEL END FASTENING PATTERN

Open Framing $mm \longrightarrow$ **Self Driller** #12-14 x 1" #12-14 x 1-1/2"

#12-14 x 2"






Woodscrew #10-14 x 1' #10-14 x 1-1/2" #10-14 x 2"




Woodscrew #10-14 x 1' #10-14 x 1-1/2" #10-14 x 2"



- Place the Sculptured Highside Eave Flashing at the peak of the roof. Lightly mark where the bottom of the Sculptured Highside Eave Flashing meets the wall panel and the top edge hits the roof panel.
- 2. Place a row of Single Bead Tape Sealant across the roof panel and over each panel rib above the mark.
- 3. Place PBR Outside Closures along the length of the highside on the roof panels. Be sure the Outside Closures are located so that the Sculptured Highside Eave Flashing will cover them.
- 4. Apply a second row of Single Bead Tape Sealant to the top of the outside closures along the highside.
- 5. Now place a row of Single Bead Tape Sealant along the top of the wall panel so that it is above the wall mark.
- 6. Place the Outside Closures or a Universal Closure over the Single Bead Tape Sealant. The Outside Closure or Universal Closure will act as a barrier to keep insects and debris from entering the building.
- 7. Apply a second row of Single Bead Tape Sealant to the top of the Outside Closures along the at the wall.
- 8. Place Sculptured Highside Eave Flashing flush against the roof and wall panels.
- 9. Fasten the Sculptured Highside Eave Flashing to the PBR roof panel through the PBR Outside Closures with Stitch Fasteners, one at every major rib.
- 10. Now fasten the Sculptured Highside Eave Flashing to the wall with Stitch Fasteners at every major rib.



RAKEWALL INSTALLATION



SUBSTRATE FASTENER INFORMATION

Open Framing



Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"

Solid Wood Substrate



Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

- 1. Place the Rakewall Flashing up against the wall and resting on the roof panel. Lightly mark the edge of the flashing on the roof panel.
- 2. Apply a row of Single Bead Tape Sealant on the major rib of the roof panel down the slope.
- 3. Lay the Rakewall Flashing down and fasten it to the PBR roof panel with a Stitch fastener one foot on center.
- 4. Now fasten the top of the Rakewall Flashing to the wall.
- 5. Install the counter flashing, reglet or wall panel and fasten to the parapet wall with the appropriate fastener one foot on center. If counter flashing or reglet is used, seal it to parapet wall with tube sealant.



ENDWALL INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL END FASTENING PATTERN

Open Framing

Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"

Solid Wood Substrate




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"



- 1. Place the Pitch Break Flashing on top of the PBR roof panels. Mark where the edge of the Pitch Break Flashing hits the PBR roof panels, upslope of your mark and downslope of the end fasteners, place a row of Single Bead Tape Sealant across the panel and over each panel rib.
- 2. Place PBR Outside Closures on top of the Single Bead Tape Sealant.
- 3. Apply a second row of Single Bead Tape Sealant to the top of the PBR Outside Closures.
- 4. Fasten the Pitch Break Flashing to the PBR roof panels through the PBR Outside Closures with Stitch Fasteners, one at every major rib.
- 5. Now fasten the top of the Pitch Break Flashing to the wall or behind the wall panel.
- 6. Install the counter flashing, reglet or wall panel and fasten to the parapet wall with the appropriate fastener one foot on center. If counter flashing or reglet is used, seal it to parapet wall with tube sealant.
- 7. If two or more flashings are required lap the flashing over the previously installed flashing by a minimum of two inches. Place a two beads of tube sealant between the flashings and secure with pop rivets two and a half inches on center.



RIDGE INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL END FASTENING PATTERN

Self Driller #12-14 x 1" #12-14 x 1-1/2"


#12-14 x 2"

Open Framing



#10-14 x 2"






- 1. Place the Universal Ridge Cover on top of the PBR roof panels. Mark the edge location of both sides of the Universal Ridge Flashing. Place a row of Single Bead Tape Sealant two inches up from your mark, across the panel and over each panel rib on both sides of the ridge.
- 2. Place PBR Outside Closures on top of the outside closures along the length of the ridge.
- 3. Apply a second row of Single Bead Tape Sealant to the top of the PBR Outside Closures.
- 4. Place the Universal Ridge Flashing down on the ridge and fasten the Universal Ridge Flashing to the PBR-Panels through the PBR Outside Closures with Stitch Fasteners, one at every major rib.
- 5. If two or more flashings are required lap the flashing over the previously installed flashing by a minimum of two inches. Place a two beads of tube sealant between the flashings and secure with pop rivets two and a half inches on center.



SCULPTURED GUTTER INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL END FASTENING PATTERN

Open Framing



Solid Wood Substrate




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"



- 1. install the Gutter Hangers. They need to be spaced at no greater than three feet on center along the gutter line.
- 2. Hold the Sculptured Gutter in place flush against the Eave Flashing. Set the Gutter Hanger on top of the major rib of the PBR roof panel and slide the Gutter Hanger into the front of the gutter. Lightly mark on the panel the end of the gutter hanger. Measure and install the other Gutter Hangers down the length of the Gutter.
- 3. Apply Single Bead Tape Sealant to the top of the ribs. Place the Gutter Hangers as marked and fasten the Gutter Hanger to the major rib of the panel with two Stitch Fasteners.
- 4. Once all of the Gutter Hangers are in place install the Sculptured Gutter flashing back against the Eave Flashing.
- 5. Fasten the back of the Sculptured Gutter flashing to the end of the roof panel with Stitch Fasteners at a maximum of one foot on center.
- 6. Now fasten the front of the Sculptured Gutter to the Gutter Hangers with Stitch Fasteners. One fastener per Gutter Hanger.
- 7. Always remember the size and gauge of the Sculptured Gutter should be designed to applicable governing building codes.



OUTSIDE CORNER INSTALLATION



SUBSTRATE FASTENER INFORMATION			OPTIONAL FLASHING
Open Framing	Solid Wood Substrate	2X Wood Framing	51/2"
			C
Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"	Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"	Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"	51/2"


INSTALLATION STEPS

Note: Outside Corner Flashings should be installed working from the ground up.

- 1. After the PBR wall panel is installed place the first Outside Corner Flashing at the base of the building.
- Install a row of Single Bead Tape Sealant on each side of the Outside Corner Flashing.
- 3. Place the Outside Corner Flashing on the wall panels.
- 4. Fasten to the wall panels with 1/4"-14 x 7/8" Stitch Fasteners, 1'-0" on center.
- 5. If more than one Outside Corner Flashing is needed then a flashing lap is required.
- 6. Apply two rows of Tube Sealant to the top of the installed Outside Corner Flashing.
- 7. Lap the flashings a minimum of 3" and fasten with Pop Rivets 2" on center.



INSIDE CORNER INSTALLATION




SUBSTRATE FASTENER INFORMATION **OPTIONAL FLASHING Open Framing Solid Wood Substrate 2X Wood Framing** mmm -> 51/2" **Self Driller** Woodscrew Woodscrew C #12-14 x 1" #10-14 x 1" #10-14 x 1" #12-14 x 1-1/2" #10-14 x 1-1/2" #10-14 x 1-1/2" 5¹/₂" #12-14 x 2" #10-14 x 2" #10-14 x 2"

INSTALLATION STEPS

Note: Inside Corner Flashings should be installed working from the ground up.

- 1. After the PBR wall panel is installed place the first Inside Corner Flashing at the base of the building.
- Install a row of Single Bead Tape Sealant on each side of the Inside Corner Flashing.
- 3. Place the Inside Corner Flashing on the wall panels.
- 4. Fasten to the wall panels with 1/4"-14 x 7/8" Stitch Fasteners, 1'-0" on center.
- 5. If more than one Inside Corner Flashing is needed then a flashing lap is required.
- 6. Apply two rows of Tube Sealant to the top of the installed Inside Corner Flashing.
- 7. Lap the flashings a minimum of 3" and fasten with Pop Rivets 2" on center.



SUBSTRATE FASTENER INFORMATION

Open Framing



Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2" **Solid Wood Substrate**




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2" **2X Wood Framing**



#10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

BASE INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL FASTENING PATTERN

Open Framing



Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"

Solid Wood Substrate




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"


2X Wood Framing



Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"



HEAD CHANNEL INSTALLATION



SUBSTRATE FASTENER INFORMATION

Open Framing



Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"

Solid Wood Substrate




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing




Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

PBR-PANEL FASTENING PATTERN



GRAVEL STOP INSTALLATION



SUBSTRATE FASTENER INFORMATION

PBR-PANEL FASTENING PATTERN

Open Framing



Self Driller #12-14 x 1" #12-14 x 1-1/2" #12-14 x 2"

Solid Wood Substrate



Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

2X Wood Framing



Woodscrew #10-14 x 1" #10-14 x 1-1/2" #10-14 x 2"

